

ADVANCED TRIKE CONCEPTS



ATTENTION:

Install ATC BIO Grips during trike assembly, per the current specifications/online promotion. Review the following steps prior to installation.

1

Remove stock grips from handlebars.

2

With shift cables detached from front and rear derailleur, pull shift lever into vertical position.

Tech tip: To simplify grip installation, remove the shifter lever from shifter body, leaving cable attached to shifter. Feed shifter lever and cable through grip prior to installing grip onto handlebar. Where applicable, secure cable housing to handlebar using electrical tape to prevent movement during grip installation.

3

Lubricate grip/handlebar using hairspray or otherwise.

4

Slide grip over shifter and onto handlebar. Refer to drawings below for proper orientation of grip.

