



Damper Bushing (GS600145)

!

Remove the upper bearing from the headset. Apply grease to the pressed race and install the Damper Bushing. Ensure the lower bearing is properly seated, and torque the threaded race to 7-9Nm. Snug the lock nut.

WARNING: Failure to match this specification will lead to adverse steering response and feel.

