



Handlebar Locator (GS600143)



1. Loosen Handlebar Clamp and remove Handlebar from the Handlebar Center - Be cautious not to stress shift and brake cables, cut zip ties if needed.
2. Slide the Handlebar Locator onto Handlebar with the Tab facing the trike.
3. Adjust the Handlebar to desired position and tighten the Handlebar Clamp.
4. Ensure the Tab on the Locator is fully seated into Slot on Handlebar Center.
5. Hold Locator in place and tighten bolt.

